

991 ESCORT

PORTABLE ZERO LLC
26045 Birch Bluff Road
Shorewood, MN 55331
Email: info@portablezero.com
www.portablezero.com

Assembly: Includes side panel A and B, 4 M4 x 14 mm Phillips machine screws, 8 self-adhesive rubber pads.

Step 1: On the **inside facing the radio** of both side panel A and B, Install 8 adhesive backed rubber pads centered over the rubber foot mounting holes as shown below.

Note: Side panel A and B are identical so they can be installed on either side. The angled frame extension faces toward the front.

Step 2: Place a M4 X 14mm screw in one of the 2 center side panel holes and position the side panels against the radio aligning the holes in the side panel with the mounting holes in the radio and carefully thread the first screw part way in.

Thread the 2nd screw carefully in place then do the final tightening on both screws. **Caution: Do not over tighten the mounting screw. Just moderate tightening is required. The tapped holes in the radio can be stripped if overtightened.**

Step 3: Install side panel B in the same manner.

Step 3: If you purchased the optional Clip on Handle and rubber feet, the rubber feet will be pre installed on your Escort side panel. Decide which side you want the feet on and install it as described above. When using the clip on handle, please install the handle with open part of the clips facing the outward as shown in the handle instructions.



Install 4 self-adhesive rubber pads on the inside of each side panel